

# Manual:Bonding Examples

## ARP Link Monitoring HowTo

### About


This is an example of aggregating multiple network interfaces into a single pipe. In particular, it is shown how to aggregate multiple virtual (EoIP) interfaces to get maximum throughput (MT) with emphasis on availability.

### Objective

You will learn how to connect remote locations via multiple physical links. The combined pipe will deliver higher throughput and availability than the individual links.

### Network Diagram

Two routers R1 and R2 are interconnected via multihop wireless links. Wireless interfaces on both sides have assigned IP addresses.



### Getting started

Bonding could be used only on OSI layer 2 (Ethernet level) connections. Thus we need to create EoIP interfaces on each of the wireless links. This is done as follows:

- on router R1:

```
[admin@MikroTik] > /interface eoip add remote-address=10.0.1.1/24 tunnel-id=1
[admin@MikroTik] > /interface eoip add remote-address=10.0.2.1/24 tunnel-id=2
```

- and on router R2

```
[admin@MikroTik] > /interface eoip add remote-address=10.1.1.1/24 tunnel-id=1
[admin@MikroTik] > /interface eoip add remote-address=10.2.2.1/24 tunnel-id=2
```

The second step is to add bonding interface and specify EoIP interfaces as slaves:

- on router R1:

```
[admin@MikroTik] > /interface bonding add slaves=eoip-tunnel1,eoip-tunnel2 mode=balance-rr
```

Refer to the following page regarding bonding mode selection.

- and on router R2

```
[admin@MikroTik] > /interface bonding add slaves=eoip-tunnel1,eoip-tunnel2 mode=balance-rr
```

The last step is to add IP addresses to the bonding interfaces:

- on router R1:

```
[admin@MikroTik] > / ip address add address 192.168.0.1/24 interface=bonding1
```

Tip: Refer to the following page regarding bonding mode selection.

- and on router R2

```
[admin@MikroTik] > / ip address add address 192.168.0.2/24 interface=bonding1
```

## Test the configuration

Now two routers are able to reach each other using addresses from the 192.168.0.0/24 network. To verify bonding interface functionality, do the following:

- on router R1:

```
[admin@MikroTik] > /interface monitor-traffic eoip-tunnel1,eoip-tunnel2
```

- and on router R2

```
[admin@MikroTik] > /tool bandwidth-test 192.168.0.1 direction=transmit
```

You should see that traffic is distributed equally across both EoIP interfaces:

```
[admin@MikroTik] > /int monitor-traffic eoip-tunnel1,eoip-tunnel2
  received-packets-per-second: 685      685
    received-bits-per-second: 8.0Mbps  8.0Mbps
      sent-packets-per-second: 21      20
        sent-bits-per-second: 11.9kbps 11.0kbps
  received-packets-per-second: 898      899
    received-bits-per-second: 10.6Mbps 10.6Mbps
      sent-packets-per-second: 20      21
        sent-bits-per-second: 11.0kbps 11.9kbps
  received-packets-per-second: 975      975
    received-bits-per-second: 11.5Mbps 11.5Mbps
      sent-packets-per-second: 22      22
        sent-bits-per-second: 12.4kbps 12.3kbps
  received-packets-per-second: 980      980
    received-bits-per-second: 11.6Mbps 11.6Mbps
      sent-packets-per-second: 21      21
        sent-bits-per-second: 11.9kbps 11.8kbps
  received-packets-per-second: 977      977
    received-bits-per-second: 11.6Mbps 11.5Mbps
      sent-packets-per-second: 21      21
        sent-bits-per-second: 11.9kbps 11.8kbps
-- [Q quit|D dump|C-z pause]
[admin@MikroTik] >
```

## Link Monitoring

It is easy to notice that with the configuration above as soon as any of individual link fails, the bonding interface throughput collapses. That's because no link monitoring is performed, consequently, the bonding driver is unaware of problems with the underlying links. Enabling link monitoring is a must in most bonding configurations. To enable ARP link monitoring (recommended), do the following:

- on router R1:

```
[admin@MikroTik] > / interface bonding set bonding1 link-monitoring=arp arp-ip-targets=192.168.0.2
```

Refer to the following page regarding bonding mode selection.

- and on router R2

```
[admin@MikroTik] > / interface bonding set bonding1 link-monitoring=arp arp-ip-targets=192.168.0.1
```

Tip: Refer to the following page for information about different link monitoring types.

# Article Sources and Contributors

**Manual:Bonding Examples** *Source:* <http://wiki.mikrotik.com/index.php?oldid=19357> *Contributors:* Eep, Eugene, Marisb, Normis, Peson

## Image Sources, Licenses and Contributors

**Image:Bonding ARP Monitoring Exam.jpg** *Source:* [http://wiki.mikrotik.com/index.php?title=File:Bonding\\_ARP\\_Monitoring\\_Exam.jpg](http://wiki.mikrotik.com/index.php?title=File:Bonding_ARP_Monitoring_Exam.jpg) *License:* unknown *Contributors:* Eugene